

Back to wall Bidet Installation- P trap

Waste Pipe setout- for Ptrap 40mm PVC pipe protruding from wall approx 30mm.

Waste height approx 140mm from finished floor

Ensure mini cocks for hot and cold water are concealed within back of pan Approx 90mm high, 80mm apart

Use short trap under bidet- connect to plug and waste (usually supplied with tap)

Connect short trap to wall waste with flexible pipe/ flexi-trap, whilst bidet positioned away from wall

Connect hot and cold water to tap

Push bidet into position against wall.

